

Using Your Crazy Catch Safely

Appropriate supervision is required at all times when used by children

Because of the very fast and unpredictable nature of the ball return from the Crazy Catch, there is risk of injury. This risk applies to anyone within the rebound area, including players and spectators.

! The risk is particularly high if a hard ball such as a cricket ball or baseball is used.

Other examples of higher risk situations include:

! Young children and less skilled / first time users

! Anyone in the rebound area who is not taking part in the Crazy Catch activity and/or not watching the ball.

! Anyone in the rebound area with others who are being irresponsible.

We recommend:

- ✓ Only use one ball and one side of the Crazy Catch at a time.
- ✓ With younger children only use softer balls, such as the Level 1 or 2 VisionBall.
- ✓ With the use of a hard ball, appropriate skill levels, behaviour and supervision are required.



Schools, Preschools, Clubs, Retailers and any workplace environment:
Please note the need for adequate supervision and correct assembly at all times

In purchasing and/or using the Crazy Catch you acknowledge that you do so at your own risk. In the event that any injury is sustained whatsoever, neither the manufacturer, distributor or retailer shall be held liable.

NEW ZEALAND TOY AND PLAYGROUND SAFETY STANDARDS APPROVED
TOY = AS NZS ISO 8124 / 1 / 2002 PLAYGROUND = AS 1924 / 2 / 1981

FRAME SAFETY FEATURES

- Between the 2 frames at least a 20mm gap is maintained throughout the full range of use options – even when opened out to 180 degrees.
- The telescoping poles have a new wrap around clip. Providing these are attached correctly the frames cannot become separated from the telescoping pole during normal use. There are also punch locators on the telescoping poles to prevent the poles from separating. Ensure that the spring clip is locked into one of the hole settings when the Crazy Catch is assembled for use.
- While the frames have been tested to withstand a static load of well in excess of 50kgs, Crazy Catch nets have not been designed nor intended for climbing.

! WARNING

**DO NOT CLIMB!
DO NOT PLACE HANDS AND FINGERS IN THE HINGE SECTION!**

**! CHOKING HAZARD!
NOT SUITABLE FOR CHILDREN UNDER 3 YEARS DUE TO SMALL PARTS**

ASSEMBLY INSTRUCTIONS (ADULT SUPERVISION REQUIRED)

INITIAL ASSEMBLY:

1 UNCLIP & ROTATE TELESCOPING POLE

2 PUSH → ATTACH RELEASE

WHEN IN USE ALWAYS HAVE THE CLIPS ATTACHED CORRECTLY

IMPORTANT:

When assembled, always ensure both clips on the telescoping support pole are attached correctly to the frames. Ensure the spring locking pin on the telescoping pole is in position to prevent the telescoping poles from sliding apart. This is to prevent the frames collapsing.

HOW TO DISCONNECT & RECONNECT FRAMES:

OPEN OUT THE FRAMES ON A FLAT SURFACE TO 180° CLIP OR UNCLIP AND SLIDE THE QUICK RELEASE PIN TO CONNECT/DISCONNECT.

PLACE UPSIDE DOWN


DO NOT USE WITH 1 HINGE ATTACHED

HOW TO ADJUST NET ANGLE TO ALTER BALL REBOUND:

ANGLED FACE OPTION
(TELESCOPING POLE POSITIONED ON GROUND)



VERTICAL / NEAR VERTICAL OPTIONS
(ACHIEVES A LOW AND/OR BOUNCING BALL REBOUND)



PRODUCT QUALITY

Your Crazy Catch has been manufactured to the highest standards, ensuring it will deliver a high level of performance over time:

3 MONTH WARRANTY All Crazy Catch products carry a 3 month guarantee against manufacturing faults.

All plastics, rubber and bungee components have been designed to extend product life with the use of UV stabilisers and appropriate materials. Also note for instance that the bungee is protected from direct impact damage from a ball against the frame.

The metal frame is very durable with a galvanised layer (both inside and outside) and outer powder coat surface. To extend product life we recommend that you store the Crazy Catch out of direct sunlight and rain when not in use for extended periods of time.

